

## Operating Instructions:


**Note:** Please make sure that you have correct model of the AR-CAL.CHECK-**X**, appropriate for your location. Model **AR-CAL.CHECK-U** is for North America and model **AR-CAL.CHECK-E** is for Europe. Do not touch metal elements during entire testing procedure.

### A1. Connect Calibration Checker with AR-7 Wrist Strap Tester



- Plug red banana plug of the AR-CAL.CHECK Calibration Checker into left, red socket of the AR-7 tester.

### B1. Connect Calibration Checker with AR-8 Wrist and Footwear Tester




- Plug red banana plug of the AR-CAL.CHECK Calibration Checker into left, red socket of the AR-8 tester.
- Plug black banana plug of the Calibration Checker into right, black socket of the AR-8 tester.

## 2. Testing Low Fail


Set the rotary switch on the front panel of the checker to the first position (Yellow circle).

### Testing AR-7 Wrist Strap Tester



- Hold Yellow banana plug properly in such a way so that your finger does not touch banana plug metal section.
- Press and hold metal pushbutton in the center of the tester with yellow banana plug
- When the calibration is correct, AR-7 tester should indicate "LO-FAIL" (Yellow LED will illuminate)
- Release the pushbutton.
- If yellow LED did not illuminate, the unit needs to be re-calibrated.

### AR-8 Wrist Strap and Footwear Tester



- Hold Yellow banana plug properly in such a way so that your finger does not touch banana plug metal section.
- Press and hold metal pushbutton on the left side of the tester (wrist strap button) with yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "LO-FAIL" (Yellow LED will illuminate)
- Release the pushbutton.
- Press and hold metal pushbutton on the right of the tester (footwear button) with yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "LO-FAIL" (Yellow LED will illuminate)
- Release the pushbutton.

### 3. Testing Pass Level

#### 3a. Testing Low Pass

Set the rotary switch on the front panel of the checker to the second position (Left Green Circle)– Low Pass

##### Testing AR-7 Wrist Strap Tester



- Press and hold metal pushbutton on the center of the tester by the yellow banana plug.
- When the calibration is correct, AR-7 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.

##### AR-8 Wrist Strap and Footwear Tester

- Press and hold metal pushbutton on the left of the tester (wrist strap button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.
- Press and hold metal pushbutton on the right of the tester (footwear button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.

#### 3b. Testing High Pass

Set the rotary switch on the front panel of the checker to the third position (Right Green Circle)– High Pass

##### Testing AR-7 Wrist Strap Tester

- Press and hold metal pushbutton on the center of the tester by the yellow banana plug.
- When the calibration is correct, AR-7 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.

##### AR-8 Wrist Strap and Footwear Tester

- Press and hold metal pushbutton on the left of the tester (wrist strap button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.
- Press and hold metal pushbutton on the right of the tester (footwear button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "PASS" (Green LED will illuminate)
- Release the pushbutton.

### 4. Testing High Fail

Set the rotary switch on the front panel of the checker to the fourth position (Red Circle)– High Fail

##### Testing AR-7 Wrist Strap Tester

- Press and hold metal pushbutton on the center of the tester by the yellow banana plug.
- When the calibration is correct, AR-7 tester should indicate "High Fail" (Red LED will illuminate)
- Release the pushbutton.

##### AR-8 Wrist Strap and Footwear Tester

- Press and hold metal pushbutton on the left of the tester (wrist strap button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "High Fail" (Red LED will illuminate)
- Release the pushbutton.
- Press and hold metal pushbutton on the right of the tester (footwear button) by the yellow banana plug.
- When the calibration is correct, AR-8 tester should indicate "High Fail" (Red LED will illuminate)
- Release the pushbutton.

**If at any time during the verification of calibration of the tester using AR-CAL.CHECK the tester does not indicate with the LED's or sound the proper color you must send the tester for factory re-calibration.)**

